DUO PAGER
USER'S MANUAL
NUMERIC PAGER

Self Test:
When user puts battery in the battery compartment, Pager starts self test with alert tone and vibration.

Display Indicators:
Message Protected : Message is saved.
Service area indicator : Antenna symbol indicates that the pager is within the service area.

Duplicated Message : If you receive a page that same page is already within your beeper, the duplicated message symbol will display.

Automatic Power On/Off : The pager shuts on and off at the selected time of the user.

Alarm : The pager will alert you at the time the user has selected.

Alert Mode : There are three kinds of alerts.
1) Chirp alert : Short beep tones
2) Audio alert
3) Vibrating alert : Vibration(no alert tone)

Low battery : It needs replacement if battery level is low.

Message Continuation : When the message is longer than 12 characters the message continuation symbol is displayed.

3**. Function description:** .
Pager on from the off screen In the pager off screen, pressing any button more than 2 seconds will turn your Pager on.
A start-up screen is displayed momentarily followed by a short beep alert While the pager is on, the standby screen is displayed. .

Turning your Pager Off :
a. From the standby screen, press and release the Mode button until "PAGER OFF is displayed.
b. Press the Read button to turn the pager off. The off screen will be displayed without any icons.

-

Receiving and Reading Message:
Your Pager can receive up twenty numeric messages. When a message is received, your Pager alerts(vibration, audio, or chirp) for eight seconds. In the corner of screen, there will be a number. The number indicates how many numeric messages were received.
a. Press any button to stop the alert.
b. Press the Read button to display the numeric message.
c. Press the Read button again to display the second screen of the message.

Message continuation:
When the numeric message is longer than 12 characters, the message continuation symbol is displayed. When the message continuation symbol is displayed, press the read button again to display the reminder of the numeric message.

-

Message Full:

- When the Pager receives up to 20 messages,-FULL- is displayed for 4 seconds. If a new message is received, the oldest unlocked message will be replaced with the new message.

-

Unread messages:

a. Unread message / If the messages are unread "UNREAD" will be displayed with the number of unread messages(ex. 01, 02, 03, etc.)

-

b. **No page:**

If no messages are received, "NO PAGES" is displayed for one second when you press read button.

-

c. **Tone Only**:

When tone only is displayed on the pager's screen, the caller paged you without sending a numeric message.

-

Duplicate Message:

If a new numeric message is received and is exactly the same as a message already in memory, the duplicated symbol is displayed to indicate that. The new duplicated message will be replaced the old duplicated message and the time stamp will also be replaced with the newer message as well. Üð.

Emergency Message:

If the caller needs to send an emergency page, the tone of the numeric message received will be different from the set alert. The caller must press 999 and then the numeric message in order to activate this option.

Message Hold time:

When you need to display your message longer than standard time (8 seconds), press and hold the read button for over 4 seconds.

Setting pager alert:

There are 3 different types of alert
Tone alert : 5 different short beep tones
Melody alert : 5 different of melodic tones
Motor alert : Vibrator with no alert tone

Setting the tone alert:

From the standby screen, press and release the mode button until "ALERT TONE" is displayed.
b. Press the read button until "TONE" is displayed.
c. Press and release the mode button until your choice of TONE 1, TONE 2, TONE 3, TONE 4 or TONE 5 is displayed. The pager produces a sample of each tone alert.
Press the read button twice to activate your selection and to return the standby screen.

Setting the melody alerts:

there are 5 melody alerts to choose from. Please follow the tone-setting instructions to set the melody alert.

Setting the vibrator alert:

a. From the standby screen, press mode button until ALERT TONE is displayed.
b. Press and release Read button until MOTOR is displayed.
c. Press Mode button to activate your selection and return to the standby screen. Ù°

Setting the silent:

Follow the vibrator alert-setting instructions to set pager silent.

Setting the alert time:

User can set Pager how long it alerts when the message is coming.

a. At the standby screen, press and release Mode button until "ALERT TIME is displayed.
b. Press and release Read button until your choice of 8-SEC,12-SEC, or 4-SEC is displayed.
c. Press Mode button to activate the selection and return to the standby screen.

Protecting and Unprotecting messages:

You can protect up to 10 messages so they are not erased or replaced by new messages.

To protect messages:

While the message is displayed, press Mode button until the lock icon it is displayed on the screen.

To unprotect message :

While the protected message is displayed with lock icon, press Mode button. The lock icon will disappear. When you have protected messages 10 messagesLOC FULL is displayed.

Erasing message(s):

a. Erasing an individual Message
From the standby screen, press and release the Mode button until "ERASE? is displayed At this point, Press the read button to select ERASE ON then press the mode button to select the message that is to be erased. After finding the message to be erased, press the read button. "SURE ? will be displayed. Press the Mode button and then ERASED is displayed. After 4 seconds, you will return the standby screen. The message selected will be completely erased. All remaining message will be moved to the next available mesage slot.

b. Erasing All message
Follow the erasing individual message instructions and select ERASE ALL instead of ERASE ON Press Mode button and SURE will be displayed. Press the Read button and COMPLETED will be displayed. All unprotected messages will be erased from memory.

15. **Time and date setting:**

a. From the standby screen, press and release the Mode button until SET TIME is displayed.
b. Press Read button. The month digits will begin to flash.
c. Press and release the Read button to set the month digits.
d. Press Mode button and day digits will begin to flash.
e. Press and release the Read button to set the date digits.
f. Press the Mode button and the hour digits will begin to flash. Follow the same instructions in step "c" and step "d" to set the hour, minute and A for AM, P for PM.

16. **Setting the alarm:**

a. To enable the alarm At the standby screen, press and release Mode button until SET ALARM is displayed. Press Read button until ALARM ON is displayed with icon Press Mode button and then the hour digit flashes Follow the time/date-setting instructions on page to set the time for the alarm to occur.

b. To disable the alarm Press and release Mode button until SET ALARM is displayed. Press Read button until ALARM OFF is displayed. Press and release Mode button Then allow the pager to automatically return to the standby screen.

18. **Automatic ON/OFF:**

User can set Pager to turn on or turn off at a selected time of day.

a. To enable automatic on/off Press and release the mode button AUTO POWER is displayed. Press Read button until AUTO ON is displayed with icon picture Press Mode button and then the hour digit flashes. Follow the time/date-setting instructions on page to set the on/off time. Press mode button to set time and hour digit flashes. Follow the above on time setting instructions.

To disable automatic on/off Press and release Mode button until AUTO POWER is displayed. Press Read button until AUTO OFF is displayed. Press and release Mode button. Then allow the pager to automatically return to the standby screen.

19. **Back–up:**

All protected messages, time/date, alarm, on/off time and all alerts remained in memory. When Pager is off and while the battery is being replaced. Press and release Mode button until BACK-UP is displayed. Press Read button and then COMPLETED is momentarily displayed and return to the standby screen.

20. **BACK LIGHT:**

In the dark conditions, the back light makes the screen easy to read. Press and hold any button over 2 seconds to activate the LCD screen back light. The back light remains on for 8 seconds and then return to the standby screen.

21. **Battery information:**

Pager operates with one AAA-size alkaline battery. When the battery is low, LOW BATT is displayed with icon. Pager alerts (short beep) 4 times every 5 minutes, prompting user to change the battery.